

DAVIS®

DAVIS®

Ginkgo Wire
Designed by Jehs+Laub



Indoor Furniture Maintenance

When cleaning an indoor version of the Ginkgo Wire family please follow the instructions listed below:

- Dust frequently with a soft, clean, and lint-free cloth.
- For heavily soiled furniture please see Outdoor Care.

Outdoor Furniture Maintenance

When cleaning an outdoor version of the Ginkgo Wire family please follow the instructions listed below:

- Start by removing any upholstered pads.
- Prepare a bucket of soapy water by adding a few drops of mild liquid detergent to warm water. Do not add any additional chemicals or cleaning products to the soapy water.
- Use a lint-free rag to wash the surface. Dip the lint-free rag in the soapy water and wring out any excess water. Gently wipe the entire furniture surface.
- Rinse the furniture with cold water.
- Allow furniture to dry completely before replacing upholstered pads.

Avoid scraping or rubbing furniture with an abrasive cloth that could damage or remove the coating from the surface. Never use ammonia or bleach on furniture.

WARNING: *Never remove glides of outdoor chairs or tables. This may cause rust.*

Note: *Rust due to exposed bare metal from scratches or chips is not considered a defect in workmanship and is not covered by the Davis Warranty.*